



RIVIERA STONES INC.

Outdoor Installation For Residential Application

Installation Instructions Including but Not Limited to:

Personal Protective Equipment

Wear appropriate personal protective equipment including work shoes, glasses, dust mask, gloves and other safety items.

Tools Required

- ✓ Measuring tape
- ✓ Mini Excavator or Skid Steers
- ✓ Straight trowel
- ✓ Diamond tipped Saw
- ✓ Bucket
- ✓ Tuck pointer
- ✓ Sponge Level
- ✓ Rubber Mallet

Preparation

- Inspect material prior to installation for any defects.
- Before laying flagstones randomly select & mix stones from several packs to minimize colour banding.
- Layout the area as per your design including level.
- Slope always away from your house walls and structures.

Laying out Flagstones

- Excavate 12" to 16" inches deep depending upon grading using mini excavator or skid steers as required.
- Prepare base using open grade gravel to 8" to 12" inches surface thickness or as needed.
- Wet- set method: Over base gravel prepare full bed of 2" inches thick sand & cement mortar to support entire flagstones, not just corners.
- Cement mortar should be prepared according to manufacturer's recommendation.
 - * Dry – laid method can also be used for installation depending upon location.
- Use rubber mallet to tap it down for correct level.
- Joints should be filled with pointed mortar or sealants .
- Brushed off any excess mortar from stone surface.
- Keep off the new patio for 24 to 36 hours weather permitting for initial setting of mortar.
- Clean patio with garden hose water to remove any construction debris.
- Riviera Stones Inc. is not liable for any damages caused due to faulty installation.
- Above guideline is for general information only.
- Buyer to retain contractor or use their own judgement for installation of stones.
- For any further information please contact office .

www.rivierastones.com

info@rivierastones.com